

# Erosion & Sediment Control Cheat Sheet

The following requirements apply to stormwater discharges from construction activities.

Direct discharges to vegetated areas.

1

Maintain natural buffers around waterways.

2

Install perimeter controls.

3

4

Minimize sediment track-out.

Minimize discharges from material stockpiles.

5

6

Minimize dust.

Minimize disturbance of steep slopes.

7

8

Preserve topsoil.

Minimize soil  
compaction.

9

10

Protect storm  
drain inlets.

Minimize  
discharges from  
stormwater  
conveyances.

11

12

Install sediment  
basins.

Minimize  
discharges from  
dewatering  
activities.

13

STILL HAVE QUESTIONS?

We can be reached at:  
(405) 329-2524

[pwstormwater@normanok.gov](mailto:pwstormwater@normanok.gov)

